Acer Aspire One 751h-1948 Battery Replacement

This guide will help you replace your battery in the Acer Aspire One 751h-1948.

Written By: Francisco Monteiro Junior



INTRODUCTION


Use this guide to replace the battery in the Acer Aspire One 751h-1948


Step 1 — Battery



- Close the laptop and flip it over to view the back of the laptop.

Step 2







- Unlock the right side of the battery by sliding the battery lock to the right. Then slide the left lock to the left and remove the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-18 02:07:10 PM.